


Service Manual

Stand for Plasma TV
TY-S58PZ700W



WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

IMPORTANT SAFETY NOTICE


There are special components used in this equipment which are important for safety. These parts are marked by  in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.

TABLE OF CONTENTS

	PAGE	PAGE
1 Safety Precautions	2	
2 Specifications	3	
3 Disassembly and Assembly Instructions	3	
4 Dimensions	5	
5 Exploded View and Replacement Parts List	6	

1 Safety Precautions

CAUTION

Do not use any the plasma TV other than those given in the catalogue.

- Otherwise the unit may fall over and become damaged, and personal injury may result.

Do not climb up on to the plasma TV or use it as a step.

- If the unit falls over or becomes damaged through misuse, injury may result.

Do not use it, when transformation and a crack take place to the stand or the glass.

- When it continues using it then, it may fall, or it may damage and personal injury may result.

Set up on a stable, level surface.

- Otherwise the unit may fall over and become damaged, and personal injury may result.

During setting-up, make sure that all screws are securely tightened.

- If sufficient care is not taken to ensure screws are properly tightened during assembly, the stand will not be strong enough to support the plasma TV, and it might fall over and become damaged, and personal injury may result.

Keep the unit away from direct sunlight and heating equipment.

- Failure to do so may result in warping, deformation, or degradation of materials, and a loss of strength that may cause the equipment to fall over or break and cause injury.

Two people are required to install and remove the plasma TV.

- If two people are not present, the plasma TV may be dropped, and personal injury may result.

Leave a space of at least 3 ¹⁵/₁₆ inches (100 mm) at the top, left and right, and at least 2 ⁴⁹/₆₄ inches (70 mm) at the rear of the plasma TV.

- The plasma TV has air outlet holes at the top and air intake holes at the bottom and rear. These holes must not be covered, otherwise fire may result.

Do not lubricate the caster in the stand.

- If the unit falls over or becomes damaged through misuse, injury may result.

Do not damage the glass.

- The Glass is tempered glass. If the unit becomes damaged through misuse, injury may result.

Do not damage it by the sharp thing. A crack advances and glass may be automatically damaged, if you use it for a long period of time after the crack has entered.



CAUTION

This stand intended for use only with Panasonic Plasma TV Models. See apparatus instructions.
Use with other models is capable of resulting in instability causing possible injury.

Models

TY-S58PZ700W: TH-58PZ700B, TH-58PZ700E, TH-58PY700F, TH-58PY700P

Notes on handling

1) Cleaning

Wipe the surfaces with a soft, dry cloth. If the unit is particularly dirty, clean it using a cloth soaked with water to which a small amount of neutral detergent has been added, and then wipe with a dry cloth.

Do not use products such as solvents, thinner or household wax for cleaning, as they can damage the surface coating.

(If using a chemically-treated cloth, follow the instructions supplied with the cloth.)

2) Do not attach sticky tape or labels, as they can make the surface of the plasma TV dirty. Do not allow long-term contact with rubber, vinyl products or the like. (Doing so will cause deterioration.)

Points to note during installation

- Insert the mains plug for the plasma TV into a mains socket which is close and easily accessible.
- Provide adequate ventilation so that the temperature around the plasma TV does not rise above 40°C (104 °F).
If there is insufficient movement of the air inside the display, heat may build up inside the plasma TV and fire may result.


2 Specifications

Dimensions (W × D × H)	
main body	57 ¹ / ₈ " (1451 mm) × 26 ³ / ₁₆ " (665 mm) × 26 ²¹ / ₃₂ " (677 mm)
with packing	63 ¹⁷ / ₆₄ " (1607 mm) × 30 ⁴³ / ₆₄ " (779 mm) × 12 ¹¹ / ₆₄ " (309 mm)
Mass (weight)	
main body	105.8lb (48 kg)
with packing	127.9lb (58 kg)


3 Disassembly and Assembly Instructions

Please assemble and install the stand according to the following procedures.

1




2



3

FRONT PANEL ASSY



4

SIDE PANEL ASSY (LEFT)

GLASS HOLDER (LEFT)


GLASS HOLDER (LEFT)

SCREW

GLASS HOLDER (RIGHT)

LOWER GLASS SHELF (TOP)




UPPER GLASS SHELF (BOTTOM) GLASS CABLE COVER



5




SCREW

CABLE COVER



4 Dimensions

TY-S58PZ700W




[Unit: inches (mm)]

5 Exploded View and Replacement Parts List

Please click the radio button for “Diagrams II / Parts List” on the menu bar.


Model No. : TY-S58PZ700W Important Safety Notice

Note: Important Safety Notice


Components identified by  mark have special characteristics important for safety.

When replacing any of these components, use only manufacturer's specified parts.

Model No. : TY-S58PZ700W Exploded View



Model No. : TY-S58PZ700W Packing Summary



Model No. : TY-S58PZ700W Parts List

Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
	1	TBLA0254	TOP CROSSPIECE	1	
	2	TBLH0648	BOTTOM BOARD ASSY	1	
	3	TBLA0276	SIDE PANEL ASSY (LEFT)	1	
	4	TBLA0277	SIDE PANEL ASSY (RIGHT)	1	
	5	TBLB0082	FRONT PANEL ASSY	1	
	6	TXFKG01JDTW	GLASS SHELF (TOP)	1	
	7	TXFKG02JDTW	GLASS SHELF (BOTTOM)	1	
	8	TBLA0266	GLASS HOLDER (LEFT)	2	
	9	TBLA0267	GLASS HOLDER (RIGHT)	2	
	10	TBLA3449	STAND POLE (LEFT)	1	
	11	TBLA3450	STAND POLE (RIGHT)	1	
	12	TBLB3132-4	REAR CABLE COVER	1	
	13	TBLB3283	GLASS CABLE COVER	1	
	14	TBLB3234	CABLE COVER	2	
	15	TBLB3074-1	CASTER (Φ30)	7	
	16	THEA182N	LONG BOLT	4	
	17	XST5+12FJ	SCREW (POLE FASTENING)	4	
	18	XSB4+10FJK	SCREW (GLASS /CORD COVER)	7	
	19	XYN5+F65FJK	SCREW (BLACK)	4	
	20	TQZH853	INSTRUCTION SHEET	1	
	21	TPCC11601	CARTON BOX	1	
	22	TPDA1505	CUSHION	1	
	23	TPDF2060	PROTECTION BOTTOM PAD	1	
	24	TPDF2061	PROTECTION BOX (GLASS)	1	
	25	TPDF2062	FIXING PAD (GLASS)	1	
	26	TPDF2063	PROTECTION PAD	1	
	27	TPDF2065	PROTECTION PAD (REAR)	2	
	28	TPDF2064	PROTECTION BOX (FRONT)	1	
	29	TPDF2066	ACCESSORY BOX	1	
	30	TPDA1535	PROTECTION CUSHION (BOTTOM)	1	
	31	TPDA1665	PROTECTION CUSHION (REAR)	1	
	32	TPDA1696	PROTECTION CUSHION	2	
	33	TPDA1697	PROTECTION CUSHION	1	
	34	TPEB328	PROTECTOR SHEET (FRONT PANEL)	1	
	35	TPEB329	PROTECTOR SHEET (BOTTOM B	1	
	36	TPEB179	SIDE PANEL SHEET	2	
	37	TPEB323	PROTECTOR SHEET (POLE)	1	
	38	TPFD155046	PROTECTION PAPER (FRONT PANEL)	1	
	39	TPFD110045	PROTECTION PAPER (GLASS)	2	
	40	XZB35X26C03	POLY BAG (GLASS HOLDER)	4	
	41	XZB17X19C03	POLY BAG	2	
	42	TPDF2067	PROTECTION BOX (BOTTOM)	1	
	43	TPDA1698	PROTECTION CUSHION	2	